

# Continuous Redial

The busy signal... we all get tired of hearing it when we are trying to place a call. With Continuous Redial, let your phone do the work for you.

## To activate



Then hang up. When the line is no longer busy, a special ring will let you know. Pick up the phone to connect the call.

## To cancel



## How to use Continuous Redial

- When you get a busy signal, hang up, pick up the receiver again and press **\*66**.
- Hang up. Continuous Redial will keep dialing the number for 30 minutes.
- When the line is no longer busy, you are notified by a distinctive ring – simply pick up the phone and the call will connect.
- You can activate Continuous Redial on up to 15 numbers. Works with most local and some long-distance numbers within your area.
- You can continue to place and receive calls while Continuous Redial is activated.
- To cancel Continuous Redial, lift the receiver and press **\*86**.

Available in most areas. Some restrictions apply. Measured service and long-distance charges may apply for completed calls.

©2011 CenturyLink, Inc. All Rights Reserved.  
CRDPO\_BE 8/11

**1 800-238-5100** for customer assistance  
[centurylink.com/bizwelcome](http://centurylink.com/bizwelcome)

